

Outboard Models Covered in This Service Manual

35 Models

E35ARLCU	J35ARLCU
E35AELCU	J35AELCU

40 Models

E40RCU	J40RCU
E40RLCU	J40RLCU
E40BACU	J40BACU
E40BALCU	J40BALCU
E40ECU	J40ECU
E40ELCU	J40ELCU
E40TECU	J40TECU
E40TELCU	J40TELCU

45 Models

E45RWLR	J45RWLR
E45RWYR	J45RWYR
E45RSR	J45RSR
E45RSLR	J45RSLR
E45RSYR	J45RSYR
E45RCCU	J45RCCU
E45RCLCU	J45RCLCU

48 Models

E48ESLCU	J48ESLCU
----------	----------

50 Models

E50BECU	J50BECU
E50BELCU	J50BELCU
E50TELCU	J50TELCU
E50TLCU	J50TLCU

55 Models

E55RWLCU	J55RWLCU
E55RSP	J55RSP
E55RSLP	J55RSLP
E55RSYP	J55RSYP