

## **GROUP INDEX**

<b>GENERAL INFORMATION</b>	<b>1</b>
<b>PERIODIC MAINTENANCE AND TUNE-UP PROCEDURE</b>	<b>2</b>
<b>SERVICING ENGINE</b>	<b>3</b>
<b>FUEL AND LUBRICATION SYSTEM</b>	<b>4</b>
<b>ELECTRICAL SYSTEM</b>	<b>5</b>
<b>CHASSIS</b>	<b>6</b>
<b>SERVICING INFORMATION</b>	<b>7</b>
<b>LT50F ('85-MODEL)</b>	<b>8</b>
<b>LT50G ('86-MODEL)</b>	<b>9</b>
<b>LT50H ('87-MODEL)</b>	<b>10</b>
<b>LT50J ('88-MODEL)</b>	<b>11</b>
<b>LT50K ('89-MODEL)</b>	<b>12</b>
<b>LT50L ('90-MODEL)</b>	<b>13</b>