

Quick Reference Guide

General Information	1
Periodic Maintenance	2
Fuel System	3
Engine Lubrication System	4
Exhaust System	5
Engine Top End	6
Engine Removal/Installation	7
Engine Bottom End	8
Cooling and Bilge Systems	9
Drive System	10
Pump and Impeller	11
Steering	12
Hull/Engine Hood	13
Electrical System	14
Storage	15
Troubleshooting	16

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.