























| | | |
|--|--|---|
| ① GEN INFO  | ② INSP ADJ  | |
| ③ CHAS  | ④ POWR TR  | |
| ⑤ COOL  | ⑥ ENG  | |
| ⑦ CARB  | ⑧ ELEC  | |
| ⑨ APPX  | ⑩  | |
| ⑪  | ⑫  | |
| ⑬  | ⑭  | |
| ⑮  | ⑯  | |
| ⑰  | ⑱  | ⑲  |
| ⑳  | ㉑  | ㉒  |

ILLUSTRATED SYMBOLS

(Refer to the illustration)

Illustrated symbols ① to ⑨ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Chassis
- ④ Power train
- ⑤ Cooling system
- ⑥ Engine
- ⑦ Carburetion
- ⑧ Electrical
- ⑨ Appendices

Illustrated symbols ⑩ to ⑮ are used to identify the specifications which appear.

- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Tightening
- ⑬ Wear limit, clearance
- ⑭ Engine speed
- ⑮ Ω , V, A

Illustrated symbols ⑯ to ㉒ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑯ Apply locking agent (LOCTITE®)
- ⑰ Apply engine oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulfide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply low-temperature lithium-soap base grease
- ㉒ Apply molybdenum disulfide grease